



Data Guide

Contents

List of Abbreviations	3
AT Commands Introduction	4
Commonly Used AT Commands	5
AT – ATtention Code	5
A/ – Repeat Last Command	5
+++ – Escape Sequence	5
A – Answer	5
D – Dial	6
Hn – Hangup	6
+CBST – Select Bearer Service Type	6
Read Command: +CBST?	7
Test Command: +CBST=?	7
S0=n – Auto Answer	7
V – Verbose Mode	7
Connecting via HyperTerminal	8
Resetting Factory Defaults	12
SIM PIN	13
Disable SIM PIN	14
3-Wire Operation	15
Autobauding	16
Uses of the +IPR command:	16
Short Burst Data (SBD)	17
Short Message Service (SMS)	19
SMS / Email Compatibility	19
Internet	20
Configuring your PC to connect to the Internet	21
Installing your Beam device as a Modem:	21
Configuring the Modem	26
Setup a Dial-up Connection	28
Note for Telstra customers	31
Configuring your Internet Browser	33
Circuit Switched Data	35
Sequence of Events:	35
Iridium Phone Numbers:	35
Scenario : Initiate a data call to a standard PSTN modem from your Beam device	36
Frequently Asked Questions	38

List of Abbreviations

Below is a list of commonly used abbreviations used throughout Iridium documentation and within this document:

ISU – Iridium Subscriber Unit
ISP – Internet Service Provider
LBT – L-Band Transceiver
MO – Mobile Originated
MT – Mobile Terminated
PPP – Point to Point Protocol
PSTN – Public Switched Telephone Network
RF – Radio Frequency
RUDICS – Router based Unrestricted Digital Interworking Connectivity Solution
SBD – Short Burst Data
SIM – Subscriber Identity Module
VAM – Value Added Manufacturer
VAR – Value Added Reseller

AT Commands Introduction

In general, modems are controlled and configured through the use of AT commands. The AT command set was originally developed by Hayes Microcomputer Products. As a result, the set of generally applicable AT commands is known as the Hayes AT Command Set. Any modem that recognizes Hayes modem commands is said to be Hayes-compatible. The Hayes AT command set is the industry standard method of communicating with and setting up a modem. Virtually all modems manufactured today are Hayes-compatible. Likewise, virtually all communications software uses Hayes modem commands to interface with the modem, including Beam devices.


Like any Hayes compatible modem, a Beam device is always in one of two modes, either **Command Mode** or **Data Mode**.

- When in command mode (also known as off-line mode), AT commands can be entered to control the device.
- When in data mode (also known as on-line mode), the device is connected to a remote system and any characters sent to it will be transmitted to the remote system.

Note: It is possible to enter the command mode without terminating a current data call by using the **+++** escape sequence described later in this document.

The following rules apply to the entry of commands:

- All commands (apart from A/ and +++) start with AT or at. The commands in a command string (apart from A/ and +++) are executed only after the return or enter key is pressed.
- Use all upper or lower case letters, not a combination.
- The maximum number of characters in a command string is 128. Multiple commands can be concatenated onto a single command line or by a semicolon.
- Command editing can usually be performed by the backspace or delete keys.
- If a parameter is missed from a basic command, a zero is implied (e.g. ATH implies ATH0). If an optional parameter is skipped from an extended command, the current value is implied. Optional parameters are enclosed by square brackets ([...]) in this document.
- Spaces can be entered into a command string to increase clarity. These are ignored.
- Characters that precede the AT prefix are ignored.
- Ctrl-x can be used to abort a command line input.



The full Iridium ISU AT Command Reference Guide is on your Beam Starter CD or available to download online from the Support section of the Beam website or directly at the following link:

http://www.beamcommunications.com/index.php?option=com_docman&task=doc_download&gid=129

Commonly Used AT Commands

AT – ATtention Code

This is the prefix for all commands except A/ and +++. When entered on its own, the ISU will respond with the OK results code.

Example: **AT**
 OK *OK – waiting for another command*

A/ – Repeat Last Command

Repeat the last command issued to the ISU unless the power was interrupted or the unit is reset. A/ is not followed by <CR>.

Example: **AT+CGMI** *Get Manufacturer*
 Iridium *Returns 'Iridium' as the manufacturer*
 OK *OK – waiting for another command*

A/ *Send the A/ to repeat last command*
 Iridium *Returns 'Iridium' as the manufacturer*
 OK *OK – waiting for another command*

+++ – Escape Sequence

The escape sequence is used to transfer from data mode to command mode without disconnecting from the remote modem. After a pause, the ISU will respond with OK. Register S2 can be used to alter the escape character from +, the factory default, to any hexadecimal value in the range 0 to 255.

Example: **"This is a data call test"** *Transfer text during a data call*
 +++ *Issue the +++ command to transfer into command mode*

OK *OK – waiting for another command*

A – Answer

Answer immediately. This causes the ISU to answer the incoming call.

Example: **RING** *Incoming data call*
 RING *" "*
 ATA *Send the 'A' command to answer the call*

CONNECT 9600 *Once the call is answered and the handshaking completed, the response 'CONNECT' coupled with the speed will be displayed as per the example.*

D – Dial

Dial a number. The dial command causes the ISU to enter originate mode and act as an auto dialler for connection to other modems. The usual format is ATDnx..x where n is a Dial Modifier and x is a number. The following are valid numbers: 0123456789*#ABC. Dial modifiers are used to alter the manner in which the ISU dials.

L Redial last number.

P Use pulse dialling (No action, compatibility only).

T Use tone dialling.

Any character received from the DTE during the call establishment phase will cause the call attempted to be terminated.

Example:	ATD+881631110006	<i>Dial phone number</i>
	CONNECT 9600	<i>Outputted once the call is established</i>
	ATDL	<i>Dials the last number</i>
	881631110006	<i>The last number dialled is displayed then dialled.</i>
	CONNECT 9600	<i>Outputted once the call is established</i>

Hn – Hangup

Control the hook switch. This command is used to clear a connection.

0 Place the ISU on hook.

Example:	ATH0	<i>Hang-up the call</i>
	OK	<i>OK – waiting for another command</i>

CBST – Select Bearer Service Type

Set Command: +CBST=[<speed>[,<name>[,<ce>]]]

Select the bearer service type for mobile originated calls.

<speed> can be of the following values:

- 0** - Autobauding
- 1** - 300 bps V.21
- 2** - 1200 bps V.22
- 4** - 2400 bps V.22bis
- 6** - 4800 bps V.32
- 7** - 9600 bps V.32 (default)
- 65** - 300 bps V.110
- 66** - 1200 bps V.110
- 68** - 2400 bps V.110
- 70** - 4800 bps V.110
- 71** - 9600 bps V.110

<name> takes the following value: **0** - data circuit asynchronous

<ce> can only take the following value: **1** - non-transparent

Example:	AT+CBST=71,0,1	<i>Set bearer speed to 71 (which is 9600 bps V110)</i>
	OK	<i>OK – waiting for another command</i>

Read Command: +CBST?

Query the current bearer service type settings. Response is in the form:

+CBST: <speed>,<name>,<ce>

Example: **AT+CBST?** *Query the currently set bearer speed*
 +CBST:007,000,001 *Returns the current bearer speed (in this case it return the*
 value of 7, which is 9600 bps V.32)

 OK *OK – waiting for another command*

Test Command: +CBST=?

List the supported <speed>, <name>, <ce>.

Response is in the form of: +CBST: (supported <speed>s),(supported <name>s),(supported <ce>s)

Example: **AT+CBST=?** *Query list of supported bearer speeds for the device*
 +CBST:(000-002,004,006-007,065-066,068,070-071),(000),(001)
 Returns list of all supported values
 OK *OK – waiting for another command*

S0=n – Auto Answer

Assigning a value from 1 to 255 in register S0 tells the ISU to automatically answer incoming calls after n rings, where n is in the range 0-255. The recommended setting is ATS0=1, which sets the ISU to answer after one ring. The setting of 0 (ATS0=0) turns off the automatic answer feature.

Example: **AT&S0=2** *Send command to auto answer after 2 rings*
 OK *OK – waiting for another command*

V – Verbose Mode

Set the response format of the ISU, which may be either numeric or textual:

0 Numeric responses

1 Textual responses (default)

Example: **ATV1** *Set verbose mode to Textual responses*
 OK *OK – waiting for another command*

Connecting via HyperTerminal

Most Beam hardware will have a serial port for configuring the device its self, plus another for accessing data services via the in-built L-Band Transceiver (LBT). This port will be labelled '**COMM Port**' on all Beam devices (with the exception of the RST600 which has only port, this being the COMM port).

The LBT is configured for data calls through the use of 'AT Commands'. This is done via HyperTerminal or an equivalent application. The following steps guide you through setting up a HyperTerminal connection to the COMM Port on your Beam device.

Before you continue, ensure you have the following resources available:


- A PC / laptop running Microsoft Windows ®
- An available COM Port
- A 9-pin straight-through serial cable



NOTE: Please consult your user manual for any specific settings before connecting to your Beam device.

1. Connect a Serial Cable between the PC COM port and the DB9 COMM Port on your Beam device.
2. Launch HyperTerminal by accessing it from the Start Menu, under Programs -> Accessories -> Communication or click Start, Run and type in *hypertrm* and click OK.


If this is the first time you have run HyperTerminal or have not previously setup your PC / Laptop for communications, you will be prompted to configure your location information for Windows® as per the below screen shot.



Simply select your country and enter your area code here.

Note that these settings will not affect the connection to your beam device.


You will then be prompted with the Windows® Phone & Modem Options dialog. As per the screenshot below:



Unless you need to make any specific changes in here, it is safe to just click OK to continue.

Note that you can access this dialog any time in the future from the Windows® Control Panel.

3. Once HyperTerminal is open, type in a name for the new Connection as per the illustration below:




Click OK on this screen.

4. Select the COM port you have your Beam device connected to on the following screen.



Click OK on this screen.

5. Although the device can accept many baud rates, we will set the Communication Port properties to 9600, 8, None, 1, None as per the illustration below:




Click OK.


You should now be connected, however nothing will appear in the HyperTerminal window yet.

To confirm you are connected, type in **AT** at the prompt.
You should receive a reply of **OK**. If not, type in **AT** again.

If you still do not receive an **OK** reply, check the connection to the PC and ensure that the COM port is not in use already and that all physical connections are secured firmly, then disconnect by selecting Disconnect from the 'Call' menu as illustrated below.




After you have disconnected, select Call from the 'Call' menu, as per the below example to reconnect.



Type in **AT** at the prompt as per earlier instruction.

If you have done everything correctly, the output response should look like the following screenshot.



Resetting Factory Defaults

While it is not always required to set the LBT back to factory defaults, it is initially advisable as the LBT could be in an unknown configuration and is a worthwhile step to ensure the device functions as expected.


At the HyperTerminal prompt, type in the following:

AT&F0 and press **Enter**, you should receive an “OK” response.

AT&W0 and press **Enter**, you should receive an “OK” response.


** Note that the “0” above is a Zero*

This saves the default settings into Profile 0 which is the default profile the LBT loads at power up.



SIM PIN

To check whether a SIM PIN is required (or the current state of the LBT), at the HyperTerminal prompt, type in the following: **AT+CPIN?**



This screenshot illustrates the response to the “CPIN?” command, and in this case informs us that it requires a SIM PIN to be entered.

The “CPIN?” command will return one of the following values:

READY	<i>ISU is not waiting for any password.</i>
PH PIN	<i>ISU is waiting for Phone Unlock Code to be given.</i>
SIM PIN	<i>ISU is waiting for SIM Card PIN1 Code to be given.</i>
SIM PUK	<i>ISU is waiting for SIM PUK to be given (because SIM PIN1 is blocked).</i>
SIM PIN2	<i>ISU is waiting for SIM PIN2 to be given*</i>
SIM PUK2	<i>ISU is waiting for SIM PUK2 to be given (because SIM PIN2 is blocked).</i>

***Note:** The response “**SIM PIN2**” is somewhat misleading, because it indicates one of three possible scenarios:




- 1) PIN1 has already been successfully entered (thus equivalent to the READY response).
 - 2) No PIN1 is required (thus equivalent to the READY response).
 - 3) The phone is waiting for PIN2 (used to access Fixed Dialing settings and other subscription-based features).
- In any of these three cases, the phone should be available to place and receive calls.*

If the return status indicates that a PIN is to be entered, you can enter this by entering the following command at the HyperTerminal prompt:

AT+CPIN="1234"

Where 1234 is replaced with your current SIM PIN.



Note that the PIN entered must be enclosed by the double quotations ("") as illustrated in the screenshot.

After the PIN has been accepted, you will receive an **OK** response from the LBT in HyperTerminal.

Disable SIM PIN


The SIM PIN prompt can be disabled so as to not prompt the user every time the unit is powered on. *Note that the following command will not work if the SIM PIN has not already been entered.*

To disable the SIM PIN prompt, from the Hyperterminal prompt, type in the following:

AT+CLCK="SC",0,"<code>" *Where <code> is the current SIM PIN.*

For example, if the SIM PIN was "1234" then to disable the prompt the following command would be entered:

AT+CLCK="SC",0,"1234"



3-Wire Operation



NOTE: If you are using a 3-wire connection instead of the standard 9-wire cable, there are some important configurations that need to be made to the LBT before normal use. On the RST100/200/310 models, DTR must be asserted before a connection can be made. For more information on how to do this, please contact Beam support.

The 9522A supports a full 9-wire interface via its Serial port, incorporating hardware handshaking and flow control. A 3-wire DTE interface (where only transmit, receive, and ground signals are used) is supported in those ISUs where the AT&D0 command has been revised to ignore the DTR (Data Terminal Ready) signal.

For three-wire operation the ISU serial interface should not be operated higher than 9600 baud in order to prevent buffer overruns due to the inherent lack of any hardware or software flow control in three-wire operation.

When operating with a 3-wire connection, the following limitations apply and must be configured accordingly:

1. The LBT must be configured to ignore the DTR input from the connected device. To configure this, from the HyperTerminal prompt, type in the following command: **AT&D0**
2. As RTS (Request To Send) and CTS (Clear To Send) hardware flow control signals will not be present, the following commands must be set for which ever is applicable:
 - (i) For No Flow Control, type in the following command at the HyperTerminal prompt: **AT&K0**
Where the "0" above is a Zero
 - (ii) For XON/XOFF Software Flow Control, type in the following command at the HyperTerminal prompt: **AT&K4**
3. Store the current / active configuration as profile 0 (zero): **AT&W0**
4. Select profile 0 (zero) as default configuration: **AT&Y0**
5. Power cycle the LBT

Some commands that will work normally with a 9-wire interface will have no effect due to the nature of the connection. These are as follows:



- **AT&Cn** setting will have no affect, as DCD (Data Carrier Detect) output to the DTE will not be present
- **AT&Sn** setting will have no affect, as DSR (Data Set Ready) output to the DTE will not be present
- RI (Ring Indicate) output to the DTE will not be present

ISU DB25	DB9	Signal
Pin 13	Pin 2	Receive Data
Pin 9	Pin 3	Transmit Data
Pin 23	Pin 5	Ground



Autobauding

On Beam terminals that share the LBT with the internal microprocessor (such as the RST100/200/310/625/810/825) the baud rate to the COM port may need to be set to match the baud of a connected device such as a Passive Data Logger. The reason being is that the microprocessor in the Beam device will set the baud rate to the speed it requires to communicate with the LBT when the data port (COMM Port) is not in use. When another passive device tries to connect to the COMM port, it will be expecting to communicate at the same baud it has been, and won't be able to.

There are 2 ways to work with this:

1 is to have the connected device send a couple of 'AT' commands to enable the LBT to auto baud, however a passive device will not have this capability.

The second option is to set the baud rate in the initial configuration, which it will revert to once the microprocessor has finished with the LBT. This is done via the use of the AT+IPR command as detailed below:

The baud rate of the LBT can be set with the "+IPR" command.

For example, to set the baud rate, the following command would be issued at the prompt:

AT+IPR=*n*

Where *n* is a value from the following list:

- 1 = 600 bps
- 2 = 1200 bps
- 3 = 2400 bps
- 4 = 4800 bps
- 5 = 9600 bps
- 6 = 19200 bps (default)
- 7 = 38400 bps



Uses of the +IPR command:

To query the current baud rate, issue the command: **AT+IPR?**

Example:	AT+IPR? +IP:006,1	<i>Query baud rate</i> <i>Baud rate is returned in the format of the above table</i>
----------	------------------------------------	---

To get a list of supported baud rates from the device, issue the command: **AT+IPR=?**

Example:	AT+IPR=? +IPR:(001-007)[,(0-1]	<i>Query supported baud rates</i> <i>Returned a list of all supported baud rates, and in this case, the device supports all of the baud rates from the list (1 thru 7).</i>
----------	---	--

To set the baud rate, issue the command: **AT+IPR=*n*** (as per the notes above)

Example:	AT+IPR=5 OK	<i>Set baud rate to 9600 bps</i> <i>Ok response indicating the command has been successful & awaiting a new command.</i>
	AT&W0 OK	<i>Save the current configuration to profile 0</i>
	AT&Y0 OK	<i>Select profile 0 as default configuration.</i>

Short Burst Data (SBD)

The 9522A LBT is capable of sending / receiving short bursts of data / messages. The maximum size of the data for Mobile Originated (MO) SBD is 1960 bytes and Mobile Terminated (MT) SBD is 1890 bytes.

Global network transmit latency for delivery of messages ranges from approximately 5 seconds for short messages to approximately 20 seconds for maximum length messages. This latency is the elapsed time before the Iridium SBD system sends the SBD message to its email destination.

Note that additional latency may be introduced by the internet or the users' host system.



NOTE: Before an SBD can be sent, the LBT must be provisioned for data. This includes Data being activated on your account and a destination address setup. The destination address can be set to a specific IMEI number, an email address, or a direct IP Address / port. – Your service provider will be able to assist you in provisioning of your device.

Sending an SBD

To send a test text message SBD packet, complete the following steps:

1. The **AT+SBDWT** command is used to store text into the LBT's buffer. At the HyperTerminal prompt, type in:

AT+SBDWT=This is my SBD message

where anything after the “=” will be the data to be stored in the LBT's buffer

2. If the string is stored successfully, you will receive an **OK** response.

3. Once the data is stored successfully in the buffer of the LBT, it can then be sent by initiating an SBD session. This is done with the command **AT+SBDI**

4. This will then send the data packet, and depending on the size of the data being sent, will take a few seconds before coming back with an **OK** response.


The below screenshot shows an example of writing the string “This is an SBD test” to the buffer and then initiating an SBD session to send the data.

```
Test - HyperTerminal
File Edit View Call Transfer Help
[Icons]
AT+SBDWT=This is an SBD test
OK
AT+SBDI
+SBDI: 1, 65, 0, 0, 0, 0
OK
```




NOTE: The length of the text message is limited to 120 bytes, due to the length limit on the AT command line interface.

In this scenario, the device has been provisioned to send data to an email address, where we receive an email similar to the following:



As you can see, the actual text message we sent is not in the main message body, but is attached to the email with a file extension of .sbd. This can be opened with any text editor such as Notepad.



More information on sending SBD packets, including writing of Binary data to an LBT can be found in the Iridium **ISU AT Command Reference** available from www.beamcommunications.com


Short Message Service (SMS)

Iridium's Short Message Service (SMS) is a mechanism to deliver Mobile Originated (MO) and Mobile Terminated (MT) short data messages over the Iridium satellite network.

Each short message can be up to 160 "text" characters (7-bit coded) in length. The text characters are based on a 7-bit alphabet which is encoded and transmitted as 8-bit data. Hence the 140 octet (byte) maximum message size. Non-text based short messages (for example, in binary format) are also possible.

The Iridium system supports 7-bit PDU format messages. The ISU is not capable of displaying, generating or storing 8-bit Text mode messages. All 8-bit Text mode messages must be generated and processed by the Field Application (FA).

Below is a screen shot of a simple SMS retrieved from a device through Hyperterminal. As you can see, it is not possible to simply read the information in legible text format, nor simply send text as you would in an email.




For more information on Iridium SMS and creating your own applications to work with the 9522A LBT, please refer to the Iridium *Short Message Service Developer's Guide* available at www.iridium.com

SMS / Email Compatibility

The below table lists the compatibility of the Iridium SIM and Telstra SIM (for customers in Australia).

<u>Iridium</u>		<u>Telstra</u>	
SMS to Iridium phone	✓	SMS to Telstra phone	✓
SMS to other network	✗	SMS to Iridium phone	✓
SMS to Email	✓	SMS to Email	✗

Internet



Direct Internet Data Service provides enhanced Internet connectivity through dedicated servers at the Iridium gateway, allowing you to execute accelerated file transfers and to more efficiently browse the Internet and exchange email. Using this service, you connect directly to the Internet, using your Beam device as a data modem. In essence, your Beam device appears as an external modem to your computer.

Direct Internet Data Service offers faster connection times, improved throughput, and Smart Connect™ features. Smart Connect™ assists you in managing your airtime by seamlessly connecting and disconnecting you through the Iridium system when no data is being transferred. This feature, called “spoofing”, will reduce airtime charges and allow you to seamlessly reconnect to the Iridium system if your connection is dropped. Airtime charges accumulate only while the call is connected.

Improved effective data throughput is achieved through the use of user-transparent data compression. The channel rate is still 2.4 Kbps. However, 10 Kbps effective throughput can be achieved depending on content (graphics and images will result in lower effective throughput).

Before using Direct Internet Data, you will need to install the client software on your computer.

For more information on Iridium Direct Internet 2 or to download the Installation files, please visit www.iridium.com

The following pages guide you through how to setup your PC / Laptop to access the internet via your Beam device with Microsoft Windows® Dialup Networking.

Configuring your PC to connect to the Internet

Installing your Beam device as a Modem:

The following instructions are based on Windows® XP and some screens will vary depending on your version of Windows®.

Firstly we need to create a new (virtual) modem in Windows® to allow us to dial. Your Beam device, once connected to your PC /Laptop will act as the modem.

To do this, click Start -> Settings -> Control Panel open the Add Hardware.




Add Hardware


Click Next on the following screen:




Select 'Yes, I have already connected the hardware' even if you have not connected your Beam device yet, then click Next.




Scroll to the bottom of the list of hardware available, and select 'Add a new hardware device' and click Next.




Select to 'Install the hardware that I manually select from a list (Advanced)'. Click Next.




Select 'Modems' from the list of available device hardware and click Next:




Check the box so that Windows® doesn't try to search for a new modem, then click Next.




From the 'Standard Modem Types', select the **Standard 19200 bps Modem** then click Next.



Select the ports that you will have your Beam device connected to, and click Next.



The modem has now been installed in Windows®. Click Finish to exit.




Configuring the Modem

We will now set the bearer speed for the connection by means of the initialization string for the modem we created. To do this, click Start -> Settings -> Control Panel open Phone and Modem Options.



Phone and Modem
Options

Select the Modems tab, and click on the Standard 19200 bps Modem, then click Properties.




Click on the Advanced tab, and type in the following string in the 'Extra initialization commands' field:

AT+CBST=71,0,1

This command set's the Bearer speed (the speed that the Beam device connects to the Iridium network) when the mode is dialled.


Refer to the 'Common AT Commands' section of this document for more information on the +CBST command.



Click OK on the properties window, then OK on the Phone and Modem Options window.

Setup a Dial-up Connection

Now that the modem is installed, we need to create a dialup connection to access the Internet. To create a new connection, click Start -> Settings -> Control Panel open Network Connections.




Network Connections

Click Next on the welcome screen.



Select the option 'Connect to the Internet' and click Next.



The screenshot shows the 'New Connection Wizard' window. The title bar is blue with the text 'New Connection Wizard'. Below the title bar, the section is titled 'Network Connection Type' with the subtitle 'What do you want to do?'. On the right side of this section is an icon of a computer with a network cable. There are four radio button options: 1. 'Connect to the Internet' (selected), with the description 'Connect to the Internet so you can browse the Web and read email.' 2. 'Connect to the network at my workplace', with the description 'Connect to a business network (using dial-up or VPN) so you can work from home, a field office, or another location.' 3. 'Set up a home or small office network', with the description 'Connect to an existing home or small office network or set up a new one.' 4. 'Set up an advanced connection', with the description 'Connect directly to another computer using your serial, parallel, or infrared port, or set up this computer so that other computers can connect to it.' At the bottom right, there are three buttons: '< Back', 'Next >', and 'Cancel'.

New Connection Wizard

Network Connection Type
What do you want to do?

☒ **Connect to the Internet**
Connect to the Internet so you can browse the Web and read email.


☐ **Connect to the network at my workplace**
Connect to a business network (using dial-up or VPN) so you can work from home, a field office, or another location.

☐ **Set up a home or small office network**
Connect to an existing home or small office network or set up a new one.

☐ **Set up an advanced connection**
Connect directly to another computer using your serial, parallel, or infrared port, or set up this computer so that other computers can connect to it.

< Back Next > Cancel

Select to 'Set up my connection manually' and click Next.



The screenshot shows the 'New Connection Wizard' window at the 'Getting Ready' step. The title bar is blue with the text 'New Connection Wizard'. Below the title bar, the section is titled 'Getting Ready' with the subtitle 'The wizard is preparing to set up your Internet connection.' On the right side of this section is an icon of a computer with a network cable. The main area asks 'How do you want to connect to the Internet?'. There are three radio button options: 1. 'Choose from a list of Internet service providers (ISPs)' 2. 'Set up my connection manually' (selected), with the description 'For a dial-up connection, you will need your account name, password, and a phone number for your ISP. For a broadband account, you won't need a phone number.' 3. 'Use the CD I got from an ISP' At the bottom right, there are three buttons: '< Back', 'Next >', and 'Cancel'.

New Connection Wizard

Getting Ready
The wizard is preparing to set up your Internet connection.

How do you want to connect to the Internet?


☐ **Choose from a list of Internet service providers (ISPs)**

☒ **Set up my connection manually**
For a dial-up connection, you will need your account name, password, and a phone number for your ISP. For a broadband account, you won't need a phone number.

☐ **Use the CD I got from an ISP**


< Back Next > Cancel

Select 'Connect using a dial-up modem', then click Next.




The screenshot shows the 'New Connection Wizard' window with the 'Internet Connection' tab selected. The title bar reads 'New Connection Wizard'. Below the tab, the text 'Internet Connection' is followed by the question 'How do you want to connect to the Internet?'. To the right is an icon of a modem. There are three radio button options: 1. 'Connect using a dial-up modem' (selected), with a description: 'This type of connection uses a modem and a regular or ISDN phone line.' 2. 'Connect using a broadband connection that requires a user name and password', with a description: 'This is a high-speed connection using either a DSL or cable modem. Your ISP may refer to this type of connection as PPPoE.' 3. 'Connect using a broadband connection that is always on', with a description: 'This is a high-speed connection using either a cable modem, DSL or LAN connection. It is always active, and doesn't require you to sign in.' At the bottom are three buttons: '< Back', 'Next >', and 'Cancel'.

Chose the Standard 19200 bps Modem from the list which will be where the Beam device is connected, then click Next.




The screenshot shows the 'New Connection Wizard' window with the 'Select a Device' tab selected. The title bar reads 'New Connection Wizard'. Below the tab, the text 'Select a Device' is followed by the instruction 'This is the device that will be used to make the connection.' To the right is an icon of a modem. The main area contains the text 'You have more than one dial-up device on your computer.' followed by 'Select the devices to use in this connection:'. Below this is a list box with two items: 'Modem - Conexant D850 56K V.9x DFVc Modem (COM3)' (unchecked) and 'Modem - Standard 19200 bps Modem (COM4)' (checked and highlighted). At the bottom are three buttons: '< Back', 'Next >', and 'Cancel'.

Give your connection a name that you will be able to identify later as per below, then click Next.



The screenshot shows the 'New Connection Wizard' window with the 'Connection Name' tab selected. The title bar reads 'New Connection Wizard'. Below the title bar, the tab is labeled 'Connection Name' with a small icon of a modem. The main text asks 'What is the name of the service that provides your Internet connection?'. Below this, it says 'Type the name of your ISP in the following box.' followed by 'ISP Name'. A text input field contains 'Iridium PPP Connection'. Below the field, it says 'The name you type here will be the name of the connection you are creating.' At the bottom, there are three buttons: '< Back', 'Next >', and 'Cancel'.

Type in the Iridium Internet number: **008816000025** then click Next.




The screenshot shows the 'New Connection Wizard' window with the 'Phone Number to Dial' tab selected. The title bar reads 'New Connection Wizard'. Below the title bar, the tab is labeled 'Phone Number to Dial' with a small icon of a modem. The main text asks 'What is your ISP's phone number?'. Below this, it says 'Type the phone number below.' followed by 'Phone number:'. A text input field contains '008816000025'. Below the field, it says 'You might need to include a "1" or the area code, or both. If you are not sure you need the extra numbers, dial the phone number on your telephone. If you hear a modem sound, the number dialed is correct.' At the bottom, there are three buttons: '< Back', 'Next >', and 'Cancel'.



Note for Telstra customers : When creating a connection to the internet, instead of using the default Iridium data number, use the Telstra data number of “**66666**” where you will receive a different call charge rate. Contact your Telstra account manager for more information.

Leave the Username & Password fields blank, as Iridium does not require authentication via this means. The 2 check boxes below are optional.



New Connection Wizard

Internet Account Information

You will need an account name and password to sign in to your Internet account.

Type an ISP account name and password, then write down this information and store it in a safe place. (If you have forgotten an existing account name or password, contact your ISP.)

User name:

Password:

Confirm password:

☐ Use this account name and password when anyone connects to the Internet from this computer

☒ Make this the default Internet connection

< Back Next > Cancel

You have now finished creating the internet connection. Click Finish to complete the setup.



New Connection Wizard

Completing the New Connection Wizard

You have successfully completed the steps needed to create the following connection:

Iridium PPP Connection

- Make this the default connection
- Share with all users of this computer

The connection will be saved in the Network Connections folder.

☐ Add a shortcut to this connection to my desktop

To create the connection and close this wizard, click Finish.



< Back Finish Cancel

Configuring your Internet Browser

Depending on your Internet Browser, certain settings will need to be set to ensure the browser is looking to access the internet via the new dial-up connection .


To do this, click Start -> Settings -> Control Panel open Internet Options.

Select the Connections tab. Click on the name of the connection you made earlier (in this case, Iridium PPP Connection). Chose to either 'Dial whenever a network connection is not present' or 'Always dial my default connection' as applicable.




Depending on the options you selected, you should now get prompted to dial a connection when you try to access the Internet via your browser.


When prompted to connect via a Dial-up connection, select your connection created earlier from the available list, then click Connect.



You may be prompted for a username & password, if so make sure both fields are blank, and click Dial, ensuring that the phone number is correct for the number to dial.




Windows will then attempt to connect, and if successful, will be notified by a balloon message in your task bar confirming you are connected to the Internet.



Note that the connection speed that Windows® reports connecting at, is the speed at which it is connecting to the Beam device through the COM port, not the speed that the Beam device is connected to the Iridium network at; This is limited to 2.4 bps.

Circuit Switched Data



Sequence of Events:

1. Application / User dials the PSTN phone number using AT Commands (e.g. 0044171.....)
2. Call request is routed over the Iridium constellation for user authentication and call set-up (~5 sec)
3. Switch makes connection to dialled number (~5 sec)
4. Analogue modem in gateway and analogue modem in remote computer synchronize (~30 sec).
5. End-to-End connection established, over the constellation, between the 2 devices.

Iridium Phone Numbers:

All Iridium data subscribers have two phone numbers, a “MSISDN” for voice calls, and a “MSISDN-C” for PSTN-to-ISU data calls.

The following dialling rules apply:

- When placing a voice call to an ISU, the caller **must** dial the **MSISDN** (Voice Number).
- When placing a PSTN-to-ISU data call, the caller **must** dial the **MSISDN-C** (Data Number).
- When placing an ISU-to-ISU data call, the caller may dial **either** the **MSISDN** or the **MSISDN-C**.

The following table shows the current Iridium numbering conventions:

MSISDN (Voice Phone Number) starts with...	MSISDN-C (Data Phone Number) starts with...
8816 214	8816 931
8816 310	8816 929
8816 314	8816 929
8816 315	8816 930
8816 317	8816 932
8816 318	8816 933
8816 762	8816 764
8816 763	8816 765
8816 766	8816 767

Scenario : Initiate a data call to a standard PSTN modem from your Beam device

Step 1 : Configure the PSTN modem to answer incoming call


Connect to the PSTN modem using Hyperterminal as outlined earlier in this document. At the Hyperterminal prompt, we will set the modem to answer automatically after 2 rings by entering the following:

AT&S0=2
OK

Press Enter
Response

AT&W0
OK

Press Enter
Response



Step 2: Send the command to dial the PSTN modem from your device

Connect the Beam device to a PC with Hyperterminal, and enter the following command:


ATDx

Where 'x' is the phone number of the PSTN modem.

For example: **ATD+61395608235** **<Enter>**


When you press Enter, the device will instigate a call over the Iridium Satellite Network and then break out over PSTN.

In the Hyperterminal window, you should receive an output similar to the following which will inform you that it is connecting and a baud rate of 9600 bps:



If the remote device is currently in a call or unavailable, you will receive a **BUSY** response from the LBT.

If HyperTerminal is connected to the PSTN modem, as the data call is being established, the output on the screen will be similar to the following:



Now the 2 devices have a data call established, text and / or files can be sent between them. You can test this by typing in the HyperTerminal window connected to one of the devices, whereby you should see your text on the other HyperTerminal window.

Additionally, files can be transferred between the 2 devices. If you are unsure on how to do this, refer to the Help menu in HyperTerminal.

Step 3 : Disconnecting

The Data call can be disconnected by either device and can be instigated in a number of ways. A preferred method is to send the following command from HyperTerminal:

+++ <Enter>
OK Should be returned after a few seconds


Once this command has been sent a few seconds later you should receive an **OK** response. Now anything you type in will be treated as a command, rather than being sent to the remote party.

To disconnect, send the following command:

ATH <Enter>
OK Should be returned

You are now disconnected.

The remote party will then receive the following response from their device:



The output 'TEST' was the text that was sent from the other device.

The output '+++' was the command sent from the other device to instigate terminating the call.

The output 'NO CARRIER' denotes that the call has been disconnected.



Note: A call can also be disconnected by dropping DTR.

Frequently Asked Questions

Q. What is the Baud Rate of the 9522A LBT?

A. The 9522A will auto-baud to the either the command '**AT**', '**at**' or a '**<CR>**' (Carriage Return). Therefore, any device that is to send data to the 9522A will need to initiate one of the above commands before transmitting data in the first instance.

Q. How do I save my settings to be the same after a power cycle?

A. To save the current configuration into profile 0 (zero), at the prompt in Hyperterminal, type in the following command: **AT&W0**

To select profile 0 (zero) as default configuration, at the prompt, use the command: **AT&Y0**

Q. What is the transfer speed of a Circuit Switch Data Call?

A. The Iridium network supports a data transfer rate of 2400 bytes p/second. Faster transfer rates are achievable when using Iridium's *Direct Internet 2* application which enables data compression. For more information on the *Direct Internet 2* application, please visit www.iridium.com


Q. How do I setup my device to auto answer?

A. At the Hyperterminal prompt, type in the following command: **AT&S0=x**

Where 'x' is the number of rings you want the device to answer after. For example **AT&S0=2** would configure the device to answer after 2 Rings. To disable Auto answer, set the 'x' value to 0.

Q. How do I check the signal strength/quality?

A. At the Hyperterminal prompt, type in the following command: **AT+CSQ**



You will receive a response in the format of **+CSQ : 5** as illustrated, where in this case the signal strength is 5. The number returned will represent how many "bars" of signal strength the unit has.

A returned value of 0 (zero) denotes that the unit has no signal or is not registered on the Iridium network.

Note: As the **AT+CSQ** command can take a few seconds to output the current signal quality, some applications may want to use the **AT+CSQF** command which will return the last known signal strength immediately.

Q. I am being prompted to enter a PIN when I connect to the device?

A. Check that you have connected to the '**COMM Port**' on the Beam device and NOT the 'Log Port'. The Log Port is used for configuring the device and you will not be able to access data services via this port.